


viewmaster^x
























57.152

v1.5


Installation manual/Installatie handleiding
Installations-handbuch/Manuel d'installation
Manuale d'installazione/Manual de instalación
Copyright ©2019 – Dataflex International BV

T +31 180 515444
F +31 180 518540
info@dataflex-int.com
www.dataflex-int.com


Parts/Onderdelen/Teile/Pièces/Parti/Partes

 1x	 1x	 1x	 1x	 1x	 1x	 1x	 1x	 3x		
 1x	 1x	 2x	 2x	 2x	 2x	 2x	 1x	 2x		
 4x	 4x	 8x								













Required tools/Benodigd gereedschap/Benötigtes Werkzeug/Outils requis/Strumenti necessari/Herramientas necesarias















viewmaster^x






or/of/oder/ou/o



viewmaster^x





No rights can be derived from this publication/
Aan deze uitgave kunnen geen rechten worden
ontleend/Aus dieser Ausgabe können keine
Rechte abgeleitet werden/Aucun droit ne peut
découler de cette publication/Dal presente
documento non deriva alcun diritto/Del
contenido de esta publicación no podrá
derivarse ningún derecho