






















57.182

v1.6


Installation manual/Installatie handleiding
 Installations-handbuch/Manuel d'installation
 Manuale d'installazione/Manual de instalación
 Copyright ©2019 – Dataflex International BV

T +31 180 515444
 F +31 180 518540
 info@dataflex-int.com
 www.dataflex-int.com


Parts/Onderdelen/Teile/Pièces/Parti/Partes

a  1x	b  2x	c  1x	d  1x	e  1x	f  1x	g  1x	h  1x	i  4x		
j  1x	k  1x	l  2x	m  3x	n  3x	o  3x	p  3x	q  1x	r  3x		
s  4x	t  4x	u  8x								













Required tools/Benodigd gereedschap/Benötigtes Werkzeug/Outils requis/Strumenti necessari/Herramientas necesarias















viewmaster^x











or/of/oder/ou/o



viewmaster^x



viewmaster^x



No rights can be derived from this publication/
Aan deze uitgave kunnen geen rechten worden
ontleend/Aus dieser Ausgabe können keine
Rechte abgeleitet werden/Aucun droit ne peut
découler de cette publication/Dal presente
documento non deriva alcun diritto/Del
contenido de esta publicación no podrá
derivarse ningún derecho