



















57.222

v1.3


Installation manual/Installatie handleiding
 Installations-handbuch/Manuel d'installation
 Manuale d'installazione/Manual de instalación
 Copyright ©2019 – Dataflex International BV

T +31 180 515444
 F +31 180 518540
info@dataflex-int.com
www.dataflex-int.com


Parts/Onderdelen/Teile/Pièces/Parti/Partes

a  1x	b  1x	c  1x	d  4x	e  1x	f  4x	g  1x	h  1x	i  4x
j  4x	k  1x	l  1x	m  1x	n  1x	o  1x	p  1x	q  1x	r  8x













Required tools/Benodigd gereedschap/Benötigtes Werkzeug/Outils requis/Strumenti necessari/Herramientas necesarias








viewmaster^x



or/of/oder/ou/o





No rights can be derived from this publication/
Aan deze uitgave kunnen geen rechten worden
ontleend/Aus dieser Ausgabe können keine
Rechte abgeleitet werden/Aucun droit ne peut
découler de cette publication/Dal presente
documento non deriva alcun diritto/Del
contenido de esta publicación no podrá
derivarse ningún derecho