




















## 57.282

v1.4


Installation manual/Installatie handleiding  
 Installations-handbuch/Manuel d'installation  
 Manuale d'installazione/Manual de instalación  
 Copyright ©2019 – Dataflex International BV

T +31 180 515444  
 F +31 180 518540  
[info@dataflex-int.com](mailto:info@dataflex-int.com)  
[www.dataflex-int.com](http://www.dataflex-int.com)


### Parts/Onderdelen/Teile/Pièces/Parti/Partes

 1x	 2x	 1x	 1x	 4x	 1x	 4x	 1x	 1x
 3x	 3x	 3x	 3x	 3x	 1x	 3x	 4x	 4x
 8x								













Required tools/Benodigd gereedschap/Benötigtes Werkzeug/Outils requis/Strumenti necessari/Herramientas necesarias















# viewmaster<sup>x</sup>








or/of/oder/ou/o



# viewmaster<sup>x</sup>





No rights can be derived from this publication/  
Aan deze uitgave kunnen geen rechten worden  
ontleend/Aus dieser Ausgabe können keine  
Rechte abgeleitet werden/Aucun droit ne peut  
découler de cette publication/Dal presente  
documento non deriva alcun diritto/Del  
contenido de esta publicación no podrá  
derivarse ningún derecho